



## WESSEX *doors*

Bessemer Close, Ebblake Industrial Estate, Verwood, Wimborne, Dorset BH31 6AZ. T: 01202 825451. F: 01202 823242.

### INSTRUCTIONS FOR FIXING G.R.P FRAMES

1. Cut side jambs to required length using first a hacksaw to cut the G.R.P. and then a wood saw to cut the timber. Please note that the head is manufactured to the size of the garage door.
2. Put the frame together putting wood glue on the dowel before inserting the jamb into the head.
3. Put the complete frame in the opening.
4. Drill three 10mm holes per jamb using a H.S.S. drill bit.
5. Drill three holes in the brickwork using 10mm masonry drill bit.
6. Countersink the G.R.P. and check that the screw is flush.
7. Use the 10 x 135 frame fixings supplied to fix the frame to brickwork using packers to ensure frame is square in the opening.
8. Use the seventh fixing to fix head if possible.
9. Push the caps supplies onto all fixing screws and use sealant between the frame and the brickwork and where the jambs meet with the head.
10. Use a damp course if deemed necessary on the bottom of the jambs to prevent damp rising up through the floor.
11. Seal frame into opening with mastic. Ensuring there is a seal around all sides on the bottom of the jamb to prevent moisture ingress into the timber core of the frame.

### PRECAUTIONS TO TAKE WHEN USING A G.R.P. FRAME

1. Do not over tighten coach bolts, as the frame will crack if they are too tight.
2. Be careful not to damage the frame, it is more fragile than normal timber.

### PACK CONTENTS

**7 No 10 x 135 frame fixings & 7 No coloured caps**